


## SL-PP55W4K60

2-way switch for 55 mm frame (white)



Thank you for choosing a SIRO light switch!  
These simple instructions will help you to install and use your new switch.




### PRODUCT FEATURES

- ▶ 4-way switch for controlling SIRO PUSHPOWER receivers
- ▶ Compatible with many 55mm switch frame systems.
- ▶ No battery and no wiring necessary!
- ▶ Battery-free device without external power supply.
- ▶ Transmission energy is generated from mechanical energy when the rocker is actuated.
- ▶ Radio-based range of up to 80 meters outdoors.
- ▶ 1 button can be connected to any number of Push Power Receivers.
- ▶ Toggle switch function when using multiple switches.
- ▶ Four independent MONO areas or two DUO areas can be controlled.
- ▶ Available in white (K60) and black (K1) versions
- ▶ Frame and base plate included in the scope of delivery.

### SWITCH DESIGN 1

Base plate

- 2 Cover frame
- 3 Radio module
- 4 Rocker (2-way)



### ASSEMBLY


- ▶ On appliance box according to DIN 49073 or on smooth, flat surfaces by screwing or gluing.
- ▶ 1. The substrate must be clean, grease-free and stable. 2. Press the base plate (1) onto the adhesive points or fix it with screws. 3. Place the cover frame (2) on the base plate. 4. Attach the radio module (3). 5. Attach the rocker (4).

### TECHNICAL FEATURES

- ▶ Transfer protocol: RF 433 mhz
- ▶ Range (without mesh): 30 meters (indoors)
- ▶ IP Rating: IP20

### DIMENSIONS

- ▶ Switch incl. frame (LxWxH): 80 x 80 x 17 mm
- ▶ Switch without frame (LxWxH): 55 x 55 x 17 mm



### SAFETY AND INSTALLATION INSTRUCTIONS

- ▶ This product is not a toy and is not suitable for children!
- ▶ The SIRO LED system is designed for indoor use.
- ▶ Unprotected outdoor use is not permitted.
- ▶ Contact with moisture must be avoided at all costs!

## SL-PP55W4K1 (white)


4-way switch for 55 mm frame

### Ideally combinable with the following SIRO PushPower products:



Receiver:	SL-PPREC02TRIAC (230V dimmable), SL-PPREC02SWITCH (230V), SL-PPREC01MONO(12-48V dimmable), SL-PPREC01DUO (12-48V dimmable)
Top hat rail:	SL-PPREC03RAIL2 (230V)
Switch socket:	SL-PPREC01AC-K60 (230V)

### GENERAL FUNCTIONS

1, 2, 3, 4	4-way buttons
Single click:	Switching on or off
Click and hold when switched on:	Dimming 2 - 100%
Double-click:	Switch off all
Click and hold when switched off:	Night mode (2% brightness)



### POSSIBLE COMBINATIONS



#### Multiple controls on one receiver

maximum of 10 PushPower controls (sensors, push buttons, etc.) can be connected to a receiver. Every option counts.

#### One control on several receivers

1 PushPower control device can control any number of receivers.

#### Radio range (depending on the local conditions)


up to 30 m indoors and up to 80 m outdoors



## FUNCTIONS IN DETAIL

### CONNECT (TEACH-IN) CONTROL UNIT (SWITCH) & RECEIVER

This is how you establish communication between the switch and your receiver:



press and hold for 3 seconds

The activity mode remains active for 22 seconds, after which the teach-in process is canceled and the light switches off.

The learning process can be canceled by disconnecting the power.

Each button/option (1&2) can be assigned its own function/option. If it is not assigned, this is a space bar.



With the DUO system, activating the first button (option 1) switches it to ON/OFF and the other button (option 2) automatically becomes the color controller. When activating several switches, they act as toggle switches.

### SINGLE CLICK - ON/OFF

A single click refers to a single, brief press of the light switch.




With SIRO light switches, a single click is used to switch the connected light source on or off.

This corresponds to the basic function of a switch, where a single click changes the status of the lighting.


### DOUBLE CLICK - SYNCHRONIZE

A double click refers to pressing the light switch twice in quick succession.



All lights are switched off. This function is used to synchronize several lights when they are running asynchronously.


### SLOW CLICK / Hold - DIMMING



A longer press on the switch can be used to continuously increase or decrease the brightness or color temperature.

This enables precise adjustment of the lighting according to individual preferences. By default, the light starts at 50% brightness or 0% cool white and 100% warm white for DUO systems. When the dimming function is activated (press and hold), the light starts dimming cyclically.

### SLOW CLICK WHEN LIGHT IS SWITCHED OFF / NIGHT MODE




A longer press (2 seconds) on the switch when it is switched off can be used to activate the night light.

The light starts at 2% brightness.

### BEHAVIOR OF THE COLOR MOOD WITH DUO RECEIVER


There are 5 settings:

- 1 ▶ 50% warm white (WW) / 50% cool white (CW)
- 2 ▶ 75% warm white (WW) / 25% cool white (CW)
- 3 ▶ 50% warm white (WW) / 50% cool white (CW)
- 4 ▶ 25% warm white (WW) / 75% cool white (CW)
- 5 ▶ 0% warm white (WW) / 100% cool white (CW)




## MEMORY FUNCTION


The system always remembers the last setting of the lighting situation before switching off. (power failure)



Behavior of the color mood with DUO Receiver: Here the system remembers the set color temperature in addition to the brightness.



## RESETTING THE RECEIVER / FACTORY STATUS



Press and hold for 10 seconds. All connections are now deleted and the receiver is ready for a new link.